

The BMW Repair Manual: 7 Series (E32): 1988-1994 is a comprehensive, single source of service information, technical specifications, and wiring schematics for the BMW 7 Series from 1988 to 1994. Whether you're a repair professional or a do-it-your-self BMW owner, this manual will help you understand, care for and repair your E32 7 Series.

New durable hardcover format - This BMW manual is now being published as a durable, long-lasting hardcover book designed to withstand many years of use in a professional shop or home garage.

Features:

- Maintenance procedures from brake fluid changes to resetting the Service Indicator. This manual tells you what to do and how and when to do it.
- Engine service, repair, and reconditioning, including valve clearance adjustment for 6-cylinder (M30) engine and camshaft timing chain setup and adjustment for V8 (M60) and V12 (M70) engines.
- Information for specific driveability problems for DME 1.2 (early and late), DME 1.3, DME 1.7, and DME 3.3 engine management systems, On-Board Diagnostics (OBD), and Electronic Throttle Control (EML).
- Suspension and brake system maintenance, troubleshooting, adjustment and repair, including ABS, traction control (ASC/ ASC+T), self levelling suspension (LAD), and electronic damping control (EDC III).
- Automatic heating and air conditioning (IHKA) repair, including A/C component replacement.
- Body adjustments and repairs.
- Wiring schematics for circuits including power distribution, grounds circuits, and an expanded electrical component location section
- Comprehensive BMW factory tolerances, wear limits, adjustments and tightening torques that you've come to expect from Bentley manuals.

BentleyPublishers .com


BMW 7 Series (E32) Service Manual: 1988-1994

735i, 735iL, 740i, 740iL, 750iL


Price: \$119.95

Bentley Stock Number: B794 Publication Date: 2005.apr.1 ISBN: 978-0-8376-1619-3 Hardcover, 8 3/8 in. x 11 in.

984 pages, 839 b/w photos, illustrations and diagrams



See how to perform routine maintenance procedures, such as checking brake pad thickness. 020 Maintenance



Detailed descriptions of engine repair procedures, including timing chain setup and adjustment for all engines. 117 Camshaft Timing Chain



Detailed, accurate electrical wiring diagrams and component location information.

610 Electrical Component Locations

7 Seres Models, engines covered

- 735i/iL (M30 3.5L engine)
- 740i/iL (M60 4.0L engine)
- 750iL (M70 5.0L engine)

Transmissions covered (remove, install, external service)

Manual Transmission

- Getrag 260/6 (5 Speed) Automatic Transmission
- 4 HP 22 (4 speed) • 4 HP 24 (4 speed)
- A5S 560 Z (5 Speed)



Bentley Publishers, 1734 Massachusetts Avenue, Cambridge, MA 02138-1804 USA Tel: 617-547-4170 • Toll Free: 800-423-4595 • Fax: 617-876-9235 http://www.bentleypublishers.com/contact-sales