



2000 Maintenance Schedule

1.8T – A4 & TT	Miles	5	10	15	20	25	30	35	40	45	50	55	60	65	70	75	80	85	90	95	100
	Kilometers	8	16	24	32	40	48	56	64	72	80	88	96	104	112	120	128	136	144	152	160
V6 & V8 – A4, A6 & A8	Miles	8	16	24	32	40	48	56	64	72	80	88	96	104	112	1205	128	136	144	152	160
	Kilometers	12	24	36	48	60	72	84	96	108	120	132	144	156	168	180	192	204	216	228	240
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Engine Filter – replace		•	•		•		•		•		•		•		•		•		•		•
Fluid Levels – check		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Auto-Shift Lock – check		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Manual Trans – check shift and clutch interlock		•	•	•	•																
Wheels – rotate*		•	•	•	•																
Service Reminder – reset		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Battery – check level			•		•		•		•		•		•		•		•		•		•
Dust/Pollen Filter – replace			•		•		•		•		•		•		•		•		•		•
Cooling System – check level			•		•		•		•		•		•		•		•		•		•
W/W System – check, add fluid			•		•		•		•		•		•		•		•		•		•
Sliding Roof – clean, lubricate rails			•		•		•		•		•		•		•		•		•		•
Transmission – check for leaks			•		•		•		•		•		•		•		•		•		•
Trans Final Drive(s) – check lubricant			•		•		•		•		•		•		•		•		•		•
Brake System – check			•		•		•		•		•		•		•		•		•		•
Drive Shafts – check boots			•		•		•		•		•		•		•		•		•		•
Wheels/Tires/Spare – check condition, pressure			•		•		•		•		•		•		•		•		•		•
OBD – check DTC memory			•		•		•		•		•		•		•		•		•		•
Exterior Lights – check, adjust			•		•		•		•		•		•		•		•		•		•
Door Hinge Mechanism – lubricate			•		•		•		•		•		•		•		•		•		•
During Road Test			•		•		•		•		•		•		•		•		•		•
After Road Test			•		•		•		•		•		•		•		•		•		•
Air Cleaner – replace					•				•				•				•			•	
Front End – check dust seals, ball joints, tie rod ends					•				•				•				•			•	
Brake Fluid – replace**					•				•				•				•			•	
Haldex Clutch-change oil***					•				•				•				•			•	
1.8T																					
Spark Plugs – replace							•						•						•		
V-Belt – replace																					
Ribbed Belt – replace																					
Timing Belt – replace****																					
Timing Belt – inspect*****																					
V6, V8																					
Spark Plugs – replace					•				•				•				•			•	
Ribbed Belt – replace										•										•	
Timing Belt – replace															•						
Timing Belt Tensioner Roller – replace†															•						

*First service only **Replace every 2 years, regardless of mileage ***TT Quattro only ****105,000 miles *****Every 40,000 miles
 † A4, A6 only