



## 2001 Maintenance Schedule

ALL Models	Miles		Kilometers											
	5	10	20	30	40	50	60	70	80	90	100	105	110	120
	8	16	32	48	64	80	96	112	128	144	160	170	180	192
Engine Oil – change	•	•	•	•	•	•	•	•	•	•	•		•	•
Engine Filter – replace	•	•	•	•	•	•	•	•	•	•	•		•	•
Service Reminder – reset	•	•	•	•	•	•	•	•	•	•	•		•	•
Wheels – rotate	•													
Fluid Levels – check	•	•	•	•	•	•	•	•	•	•	•		•	•
Auto-Shift Lock – check	•	•	•	•	•	•	•	•	•	•	•		•	•
Brake System – check	•	•	•	•	•	•	•	•	•	•	•		•	•
Manual Trans – check shift and clutch interlock	•	•	•	•	•	•	•	•	•	•	•		•	•
Cooling System – check level	•	•	•	•	•	•	•	•	•	•	•		•	•
Exhaust System - check	•	•	•	•	•	•	•	•	•	•	•		•	•
OBD – check DTC memory	•	•	•	•	•	•	•	•	•	•	•		•	•
Door Hinge Mechanism – lubricate		•	•	•	•	•	•	•	•	•	•			•
Battery – check level		•	•	•	•	•	•	•	•	•	•		•	•
W/W System – check, add fluid		•	•	•	•	•	•	•	•	•	•		•	•
Wheels/Tires/Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•		•	•
Drive Shafts – check boots		•	•	•	•	•	•	•	•	•	•		•	•
Road Test		•	•	•	•	•	•	•	•	•	•		•	•
Lights – check		•	•	•	•	•	•	•	•	•	•		•	•
Engine - check for leaks			•		•		•		•		•			•
Front End – check dust seals, ball joints, tie rod ends			•		•		•		•		•			•
Haldex Clutch - change oil & filter*			•		•		•		•		•			•
Transmission – check for leaks			•		•		•		•		•			•
Trans Final Drive (man/auto) – check lubricant			•		•		•		•		•			•
			m		m/a		m		m/a		m			m/a
Dust/Pollen Filter – replace			•		•		•		•		•			•
Head Lights - adjust			•		•		•		•		•			•
Sliding Roof – clean, lubricate rails			•		•		•		•		•			•
Power Steering Fluid - check					•				•					•
Air Cleaner – replace element					•				•					•
Spark Plugs – replace					•				•					•
V-Belt – replace**									•					•
Ribbed Belt – replace									•					•
Timing Belt – inspect****					•				•					•
Timing Belt – replace***													•	
Timing Belt Tensioner Roller – replace*****													•	

\* TT quattro \*\*1.8L Turbo \*\*\* 1.8L, 2.7L V6 and 4.2L V8 \*\*\*\* A4, TT 1.8L every 40,000 miles \*\*\*\*\*2.8L V6  
 Brake Fluid-replace every 2 years, regardless of mileage