



## 2002 Maintenance Schedule A4/S4

	Miles	10	20	30	40	50	60	70	80	90	100	105
Kilometers		16	32	48	64	80	96	112	128	144	160	170
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	
Engine Oil Filter – replace		•	•	•	•	•	•	•	•	•	•	
Engine - check for leaks		•		•		•		•		•		•
Cooling System – check level, add if necessary		•	•	•	•	•	•	•	•	•	•	
Exhaust System – check for damage, leaks		•	•	•	•	•	•	•	•	•	•	
Engine OBD – check memory, purge		•	•	•	•	•	•	•	•	•	•	
Door Hinge Mechanisms – lubricate		•	•	•	•	•	•	•	•	•	•	
Battery – check level		•	•	•	•	•	•	•	•	•	•	
Wiper/Washer – check fluid, add if necessary		•	•	•	•	•	•	•	•	•	•	
Auto-Shift Lock – check		•	•	•	•	•	•	•	•	•	•	
Manual Transmission – check shift and interlock		•	•	•	•	•	•	•	•	•	•	
Tires & Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•	
Service Reminder – reset		•	•	•	•	•	•	•	•	•	•	
Brake System – check		•	•	•	•	•	•	•	•	•	•	
Drive Shafts – check boots		•	•	•	•	•	•	•	•	•	•	
Road Test		•	•	•	•	•	•	•	•	•	•	
Lights – check		•	•	•	•	•	•	•	•	•	•	
Front Axle – check dust seals, ball joints, tie rod ends			•		•		•		•		•	
Automatic Transmission – check for leaks			•		•		•		•		•	
Automatic Transmission Final Drive – check for leaks					•				•			
Manual Transmission - check for leaks			•		•		•		•		•	
Manual Transmission Final Drive – check for leaks			•		•		•		•		•	
Multitronic Transmission - change ATF					•							
Power Steering Fluid - check					•							
Dust/Pollen Filter – replace			•		•		•		•		•	
Headlights – inspect, adjust if necessary			•		•				•		•	
Sliding Roof – clean, lubricate rails			•		•		•		•		•	
Air Cleaner – replace filter element									•			
Spark Plugs – replace						•				•		
Ribbed Belt – replace									•			
Ribbed Belt – check* **												•
Timing Belt – inspect***					•				•			
Timing Belt – replace* **												•
Timing Belt and Tensioner Roller – replace ****												•

Brake Fluid - replace every 2 years, regardless of mileage.  
 \*1.8T    \*\* 3.0L    \*\*\*A4 1.8L every 40,000 miles    \*\*\*\*2.7L



# 2002 Maintenance Schedule A6/S6/allroad

	Miles	10	20	30	40	50	60	70	80	90	100	105
Kilometers		15	30	45	60	75	90	105	120	135	150	155
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	
Engine Oil Filter – replace		•	•	•	•	•	•	•	•	•	•	
Engine – check for leaks			•		•		•		•		•	
Cooling System – check level, add if necessary		•	•	•	•	•	•	•	•	•	•	
Exhaust System – check for damage, leaks		•			•		•		•		•	
Engine OBD – check memory, update		•	•	•	•	•	•	•	•	•	•	
Door Hinge Mechanisms – lubricate		•	•	•	•	•	•			•	•	•
Battery – check electrolyte, add if necessary		•	•	•	•	•	•	•	•	•	•	•
Wiper/Washer – check fluid, add if necessary		•	•	•	•	•	•	•	•	•	•	•
Automatic Shift Lock – check		•	•	•	•	•	•	•	•	•	•	•
Manual Transmission – check shift and interlock		•	•	•	•	•	•	•	•	•	•	•
Tires and Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•	•
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•	•
Brake System – check		•	•	•	•	•	•	•	•	•	•	•
Drive Shaft Boots – check		•	•	•	•	•	•	•	•	•	•	•
Road Test		•	•	•	•	•	•	•	•	•	•	•
Lights – check		•	•	•	•	•	•	•	•	•	•	•
Front Axle – check dust seals, ball joints, tie-rod ends			•		•				•		•	
Automatic Transmission – check for leaks			•		•		•		•		•	
Automatic Transmission Final Drive – check for leaks									•		•	
Manual Transmission – check for leaks			•		•		•		•		•	
Manual Transmission Final Drive – check for leaks			•		•		•				•	
Multitronic™ Transmission – change ATF					•				•		•	
Power Steering Fluid – check, add if necessary					•				•		•	
Dust and Pollen Filter – replace			•		•		•		•		•	
Headlights – inspect, adjust if necessary			•		•		•		•		•	
Sliding Roof – clean, lubricate rails			•		•		•		•		•	
Air Cleaner – replace filter element					•				•		•	
Spark Plugs – replace					•				•		•	
Ribbed Belt – replace									•		•	
Ribbed Belt – check**												•
Timing Belt – replace** ***												•
Timing Belt and Tensioner Roller – replace*												•

Brake Fluid – replace every 2 years, regardless of mileage.  
W42AUMAINT2002A4S4A6S6 Printed October 2001

\*2.7L

\*\*3.0L

\*\*\*4.2L



# 2002 Maintenance Schedule A8/S8

	Miles	10	20	30	40	50	60	70	80	90	100	105
Kilometers		15	30	45	60	75	90	105	120	135	150	155
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	
Engine Oil Filter – replace		•	•	•	•	•	•	•	•	•	•	
Engine – check for leaks			•		•		•		•		•	
Cooling System – check level, add if necessary		•	•	•	•	•	•	•	•	•	•	
Exhaust System – check for damage, leaks		•			•		•		•		•	
Engine OBD – check memory, purge		•	•	•	•	•	•	•	•	•	•	
Door Hinge Mechanisms – lubricate		•	•	•	•	•	•		•		•	
Battery – check electrolyte, add if necessary		•	•	•	•	•	•	•	•	•	•	
Wiper/Washer – check fluid, add if necessary		•	•	•	•	•	•	•	•	•	•	
Automatic Shift Lock – check		•	•	•	•	•	•	•	•	•	•	
Tires and Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•	
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•	
Brake System – check		•	•	•	•	•	•	•	•	•	•	
Drive Shaft Boots – check		•	•	•	•	•	•	•	•	•	•	
Road Test		•	•	•	•	•	•	•	•	•	•	
Lights – check		•	•	•	•	•	•	•	•	•	•	
Front Axle – check dust seals, ball joints, tie-rod ends			•		•		•		•		•	
Automatic Transmission – check for leaks			•		•		•		•		•	
Automatic Transmission Final Drive – check for leaks					•				•		•	
Power Steering Fluid – check, add if necessary					•				•		•	
Dust and Pollen Filter – replace			•		•		•		•		•	
Headlights – inspect, adjust if necessary			•		•		•		•		•	
Sliding Roof – clean, lubricate rails			•		•		•		•		•	
Air Cleaner – replace filter element					•				•		•	
Spark Plugs – replace					•				•		•	
Timing Belt – replace												•

Brake Fluid – replace every 2 years, regardless of mileage.



## 2002 Maintenance Schedule TT

	Miles	10	20	30	40	50	60	70	80	90	100	105
Kilometers		16	32	48	64	80	96	112	128	144	160	170
Engine Oil – change		•	•	•	•	•	•	•	•	•	•	
Engine Oil Filter – replace		•	•	•	•	•	•	•	•	•	•	
Engine - check for leaks		•		•		•		•		•		•
Cooling System – check level, add if necessary		•	•	•	•	•	•	•	•	•	•	
Exhaust System – check for damage, leaks		•	•	•	•	•	•	•	•	•	•	
Engine OBD – check memory, purge		•	•	•	•	•	•	•	•	•	•	
Door Hinge Mechanisms – lubricate		•	•	•	•	•	•	•	•	•	•	
Battery – check electrolyte, add if necessary		•	•	•	•	•	•	•	•	•	•	
Wiper/Washer – check fluid, add if necessary		•	•	•	•	•	•	•	•	•	•	
Manual Transmission – check shift and interlock		•	•	•	•	•	•	•	•	•	•	
Tires & Spare – check condition, pressure		•	•	•	•	•	•	•	•	•	•	
Service Reminder Display – reset		•	•	•	•	•	•	•	•	•	•	
Brake System – check		•	•	•	•	•	•	•	•	•	•	
Drive Shafts – check		•	•	•	•	•	•	•	•	•	•	
Road Test		•	•	•	•	•	•	•	•	•	•	
Lights – check		•	•	•	•	•	•	•	•	•	•	
Front Axle – check dust seals, ball joints, tie rod ends			•		•		•		•		•	
Haldex Clutch – change oil and filter			•		•		•		•		•	
Manual Transmission - check for leaks			•		•		•		•		•	
Manual Transmission Final Drive – check for leaks			•		•		•		•		•	
Power Steering Fluid – check, add if necessary				•				•				
Dust/Pollen Filter – replace			•		•		•		•		•	
Headlights – inspect, adjust if necessary			•		•		•		•		•	
Air Cleaner – replace filter element				•				•				
Spark Plugs – replace				•				•				
Timing Belt – replace												•
Ribbed Belt – check												•
Timing Belt – inspect*								•				

Brake Fluid - replace every 2 years, regardless of mileage  
 \*TT 1.8L every 40,000 miles