

## **Audi Service**

## 2009 Scheduled Maintenance Intervals

Miles (in thousands)	5/25/45/65/85/105/125	15/55/95	35/75/115
Kilometres (in thousands)	8/40/70/100/130/160/200	25/85/145	55/115/175
Engine Oil/Oil Filter – change oil and replace filter	•	•	•
Wiper Blades – check condition and replace if necessary	•		•
Wiper/Washer/Headlight Washer – check adjustment and function,	•		•
add fluid if necessary			
Tires and Spare – check for wear and damage, check pressure	•		115K only
<ul> <li>check for wear and damage, check pressure and renewal date of tire set (where applicable)</li> </ul>		•	35K/75K only
Tires – rotate  Service Reminder Display – reset  Brake System – check for damage, leaks, pad thickness, fluid level bishers.com [B  Cooling System – check level, add if necessary  Exhaust System – check for damage, leaks	● 5K only		
Service Reminder Display – reset	1.0	•	•
Brake System – check for damage, leaks, pad thickness, fluid leyelbishers.com	BentleyPublic	•	•
Cooling System – check for damage, leaks, pad thickness, fluid legations  Exhaust System – check for damage, leaks	- "oners.co	•	•
Exhaust System – check for damage, leaks	(V)	•	•
Engine On Board Diagnostics – check fault memorx	· · · · · · · · · · · · · · · · · · ·	A3, A4 Cab, S4, A6, S6, A8, S8 only	A3, A4 Cab, S4, A6, S6, A8, S8 only
Engine Compartment – check for leaks  Battery – check and replace if necessary  Dust and Pollon Filter, replace		OS, TO, OS ONLY	0
Battery – check and replace if necessary		<sup>9</sup> / <sub>2</sub> / <sub>2</sub>	•
Dust and Pollen Filter – replace			•
Automatic Transmission and Final Drive & theck for leaks		• 76.	•
Manual Transmission and Final Drive – check for leaks			•
Haldex Clutch – change oil		• *c o m	A3, TT only
Front Axle – check for excessive play, check dust seals on ball joints and			A3, 11 only
tie rod ends		A3, A4 Cbb, S4, A6, S6, A8, S8 only	
<u>6</u>		<u> </u>	A3. A4 Cab. S4. A6. S6.
Lights – check all lights, check headight adjustment		A8, S8 only	A3, A4 Cab, S4, A6, S6, A8, S8 only
Drive Shaft Boots – check		уР	•
Doors – lubricate doors, check strags and hood latch		A8, S8 only	Except A8, S8
Spark Plugs – replace at 35,000 miles or 3 years, whichever occurs first.  Then, every 40,000 miles or 3 years, whichever occurs first.		shers	<ul> <li>35K/115K only:</li> <li>A3 3.2L, TT 3.2L,</li> <li>A8 6.0L only</li> </ul>
– replace at 55,000 miles or 6 years, whichever occurs first.		● 55K only: except A3 3.2L, T1 3.2L, A8 6.0L	
Then, every 60,000 miles or 6 years, whichever occurs first.		A3 3.2L, 1 13.2L, A8 6.0L	
- replace at 75,000 miles		[B	75K only: A3 3.2L, TT 3.2L, A8 6.0L only
Continuously Variable Transmission (Multitronic) – change ATF			•
Power Steering Fluid – check, add if necessary		8	•
Air Cleaner – clean housing, replace filter element		• 5a conly: except	35K only: A8 6.0L only 75K only: Audi Q7 4.2L, A8 6.0L only 115K only: A8 6.0L only
		R8 only	A8 6.0L only 115K only: A8 6.0L only
Ribbed V Belt and Tensioner – check condition and replace if necessary		R8 only	Audi Q7 3.6L, A8 6.0L, R8 only
Ribbed V Belt – replace		3,9	75K only: S4 only
– check condition, replace if necessary, Check tension of		III.	75K only: V6 FSI,
belt drive with manual tensioner and retension if necessary.	(E)	<b>S</b>	75K only: V6 FSI, V6 TFSI (rear belt), 2.0LTFSI, 5.2L FSI, 4.2L FSI
– replace only the V belt for the compressor draye	moo.erahelldushelmag lej		75K only: 3.0T FSI only
Snow Screen for Air Cleaner – clean Underbody – check for damage and leaks	- ionzildug <sub>ke</sub>	A4, A5, S5 and A6 only	A4, A5, S5 and A6 only
Underbody – check for damage and leaks	1 moo.8764	and Ad diny	and Ad drilly
Road Test – check braking, kick-down, steering, electrical, heating and ventilation systems, air conditioning, ASL Automatic Shift Lock and power accessories		•	•
Rear Lid Hinges – lubricate		A8, S8 only	A8, S8 only
Horn – check function		Ab, 36 Ully	Ao, 30 only
Brake Discs – check thickness			•
Lights – check all lights via instrument cluster. Check license plate light from the rear of the vehicle			Audi Q7, A4 (B8 only), S4, Audi Q5, TT, A5, S5, R8 only
Interior Lights – check all interior lights, glove box illumination, control lights and MMI (if applicable)			•
DSG/S Tronic – change oil and replace filter element			A3, TT only
AdBlue Fluid – fill completely with fresh fluid (23 liters)	Audi Q7 3.0L TDI only	Audi Q7 3.0L TDI only	Audi Q7 3.0L TDI only
Fuel Filter – remove water		Audi Q7 3.0L TDI only	
- replace			Audi Q7 3.0L TDI only
Diesel Particle Filter (DPF) – check ash content within the DPF. Replace DPF with	125K anh. 4 . U 07		Addi Q7 3.0L TDI only
an ash content greater than or equal to .46 liters.	125K only: Audi Q7 3.0L TDI only		
Plenum Panel – clean if dirty (except A3, Audi Q5)		•	•

At 110k miles (175 km) replace timing belt on Audi TT 2.0T with front wheel drive and A4 Cabriolet 2.0T only. Check condition of timing belt tensioning system, dampening pulleys, and idler pulleys and replace if necessary (Audi TT 2.0T with front wheel drive and A4 Cabriolet 2.0T only).

Brake Fluid – replace every 2 years regardless of mileage.

Cloth Top – check function and rollover protection every 2 years regardless of mileage (Audi A4/S4 Cabriolet only).

Audi of America, Inc. believes the information and specifications to be correct at the time of printing. Specifications, maintenance intervals, standard features and options subject to change

without notice. Revised 10/27/2008